



## Life Racing – Wideband Wiring

### NTK Sensor

Yellow	Heater -	=	Life Pin 50	fuel output to switch on	Green
Blue	Heater +	=	Life 12V supply	Sharded 12v Ecu	Black
White	Lamba IP	=	Life Pin 76	IP	Blue
Gray	Lamba Vs	=	Life Pin 18	VS	Red
Black	0v Ground	=	Life Pin 77	Dedicated Ecu Ground	Brown

Please note this is only a guide, we reserve the right to change any contents and prices at any time without notification.